

RHINO CARBON FIBER™ CRACK REPAIR KIT INSTRUCTIONS

Revision Date 06/16/2021

8383 Riley Street,
Zeeland, MI USA 49464
P: +1 888 684 3889
E: info@rhinocarbonfiber.com

01

WHAT COMES IN THE CRACK REPAIR KIT?



KIT INCLUDES

- (1) 12" wide carbon fiber strap (length is determined by kind of kit)
- (2) Tubes of Saturant-Adhesive Epoxy
- (2) Static epoxy mixing nozzles
- Gloves and Instructions

PRODUCTS COMMONLY USED WITH CRACK REPAIR



Rhino Carbon Fiber™ Dual Epoxy Gun
300/300 ml or 300/150 ml gun



Rhino Carbon Fiber™ Concrete Crack Lock™ stitches
Adds extra strength during repair



RCF™ High Strength Anchoring Epoxy Paste
Used to fill cracks

RECOMMENDED POWER TOOLS

5-Inch Surface Grinding Dust Shroud Kit



Use for grinding foundation wall
**USE DIAMOND CUP WHEEL

10-Gallon HEPA Dust Extractor



Collects dust while attached to grinder and shroud tools

Tuck Point Grinder with Dust Shroud Attachment



Use to tuckpoint the wall
**USE DIAMOND EDGE BLADE

Hammer Drill



Use for concrete removal
**USE CHISEL OR SPADE TIP ATTACHMENT

YOU WILL ALSO NEED...

- Safety goggles
- Respirator mask
- Hard hat
- Coveralls
- Drop cloth
- Gravel
- Scissors
- Marker
- Hydraulic cement
- Epoxy gun
- Measuring tape
- Shovel/bucket

SAFETY WARNINGS

Please read and follow safety procedures for all tools and wear proper safety equipment during installation.

While using power tools, follow all EPA/OSHA guidelines for lead paint removal and respiratory protection. For more information visit www.epa.gov or www.osha.gov.



1-888-684-3889 | www.RhinoCarbonFiber.com



© All Rights Reserved

RHINO CARBON FIBER™ CRACK REPAIR KIT INSTRUCTIONS

Revision Date 06/16/2021

8383 Riley Street,
Zeeland, MI USA 49464
P: +1 888 684 3889
E: info@rhinocarbonfiber.com

02

PLEASE READ ALL DIRECTIONS CAREFULLY & WEAR SAFETY GOGGLES BEFORE INSTALLING



01 PREP

- Locate where Rhino Carbon Fiber Crack Repair Kit will be installed
- Mark the crack at the top, middle and bottom of the wall
- Mark 7" on both sides of the crack at top, bottom and middle locations

Tools: marker



02 CONCRETE REMOVAL

- Remove 14" of the concrete floor centered on the crack down to the footer

Note: Concrete should be removed past the edge of the footer

Recommended Tools: hammer drill



03 GRINDING

- Grind the foundation wall where the crack repair material will be installed (use previously marked locations as a guide)
- Achieve a "Bare Foundation"
- Rhino Carbon Fiber Crack Repair should span from the sill plate to the footer

Note: Remove all caulk/latex/etc. from work area

Tools: grinder



04 FILL

- Option 1: Fill the crack with High Strength Anchoring Epoxy Paste or hydraulic cement prior to mounting the carbon fiber
- Option 2: Inject the crack with Rhino's Injection products

Note: only fill the crack in areas that are above the slab, so there is a release for any water that gets into the crack

Tools: high strength anchoring epoxy paste or hydraulic cement and epoxy gun



1-888-684-3889 | www.RhinoCarbonFiber.com

© All Rights Reserved

None of the authors, contributors, administrators, or anyone else connected with Rhino Products USA Inc. or any of its affiliates (collectively, "Rhino"), in any way whatsoever, can be responsible for your use of the information, instructions or advice contained in or linked from this or any related document. All liability with respect to actions taken or not taken based on the contents of this or any related document is hereby expressly disclaimed by Rhino. The content of this document is provided "as is;" no representations are made that the content is error-free.

RHINO CARBON FIBER™ CRACK REPAIR KIT INSTRUCTIONS

Revision Date 06/16/2021

8383 Riley Street,
Zeeland, MI USA 49464
P: +1 888 684 3889
E: info@rhinocarbonfiber.com

03



06 MOUNT

- Measure the height of the foundation wall from the sill plate to the footer and add 6"
- Cut carbon fiber to length
- Make sure crack will be completely covered by carbon fiber
- Install a thin layer of gravel on top of the footer to provide a release for any water that comes through the crack

Tools: measuring tape and scissors/utility knife



07 EPOXY

- Apply a thin layer of epoxy to the foundation wall working from top to bottom covering the entire prepped surface using squeegee, trowel epoxy to achieve a uniform coating of epoxy
- Once a sufficient coating of epoxy is applied to foundation wall, lay carbon fiber crack repair over the epoxy ensuring the carbon fiber completely covers the crack
- Use light strokes with desired tool to spread epoxy in the direction of the tows if the carbon fiber is unidirectional


Tools: saturant-adhesive epoxy, epoxy gun and squeegee



05 BACKFILL REPLACEMENT

- Using gravel or small pieces of concrete leftover from removal, fill area leaving a minimum of 3" for new concrete

Tools: gravel



08 FINISH

- Mix concrete per manufacturer's recommendation
- Pour concrete into work area and trowel to a smooth, uniform finish

Tools: concrete, bucket, shovel and trowel



1-888-684-3889 | www.RhinoCarbonFiber.com

© All Rights Reserved

None of the authors, contributors, administrators, or anyone else connected with Rhino Products USA Inc. or any of its affiliates (collectively, "Rhino"), in any way whatsoever, can be responsible for your use of the information, instructions or advice contained in or linked from this or any related document. All liability with respect to actions taken or not taken based on the contents of this or any related document is hereby expressly disclaimed by Rhino. The content of this document is provided "as is;" no representations are made that the content is error-free.